
QUICK INSTALLATION GUIDE

**Ethernet
PC Card
for 10-Base-T**

STI-10BASET

Simple
TECHNOLOGY
INCORPORATED

Introduction

This is the quick installation guide for the 10-BASE-T Ethernet PC Card. This guide consists of the following sections: 1) *Installing the Network Drivers*; 2) *Connecting the Card*; 3) *Removing the Card*; and 4) *Technical Support*.

NOTE: *For information on FCC and DOC compliance, refer to the Installation Guide included with the PC Card.*

Consult the guide that comes with your computer to locate the PCMCIA (PC Card) Type II socket. Read additional information from the computer guide regarding specific instructions on using the socket, then proceed to *Installing the Network Drivers*.

Installing the Network Drivers

Proceed to the section below appropriate to your operating system.

Windows 95

1. Start Windows 95.
2. Plug the card into the computer socket. The card is keyed and will complete insertion only in the proper orientation. Do not force the card into the socket.
3. Windows 95 may respond with the New Hardware Found dialog box. If this is the case, insert the Network Drivers Diskette into drive A. Make sure "Driver from disk provided by hardware manufacturer" is selected, then click on "OK." Windows 95 may ask you to insert specific diskettes from the original Windows 95 distribution. Follow the on-screen instructions.
4. When the driver installation is complete, proceed to *Connecting the Card*.

Windows 3.1 and Novell, or Windows for Workgroups

NOTE: *Your computer must have Card and Socket Services compliant to PCMCIA Specifications Release 2.1 or higher installed. Card and Socket Services are normally provided with the computer. If Card and Socket Services are not installed, you must install Card and Socket Services before proceeding.*

1. Start Windows 3. x or Windows for Workgroups.
 2. Insert the Network Drivers Diskette into drive A.
 3. Select Run from the Program Manager File Menu. The Run dialog box appears.
 4. Type: A:\Setup. Click on OK. A dialog box appears. After reading the dialog box, click on Continue.
 5. The network selection dialog box appears. Select the appropriate network and click on Continue.
 6. The configuration dialog box appears. To accept the default configuration and copy the drivers to the drive and directory listed, click on Install. The drivers are copied to the drive and directory listed in the "Install to" section of configuration dialog box.
 7. When the installation is complete, a completion dialog box appears. After reading the text, click on OK.
-

-
8. Proceed to *Connecting the Card*.

Connecting the Card

1. Start Windows 3.x, Windows for Workgroups, or Windows 95.
2. Using the adapter cable provided and a twisted-pair cable with a RJ45 connector, connect the card to the network.
3. Plug the card into the computer socket. The card is keyed and will complete insertion only in the proper orientation. Do not force the card into the socket.
4. The computer will beep when it recognizes the card. For Windows 95, the PCMCIA icon appears on the right of the task bar.
5. Log on to the network.

Removing the Card

Proceed to the section below appropriate to your operating system.

Windows 95

1. Log off the network.
2. Double-click with the normal-select mouse button on the PCMCIA icon located on the right of the task bar. The "PC Card Properties" window appears. Select the card from the list. Click on the "Stop" button. Wait until you are prompted to remove the card, then proceed to *Step 3*.
3. If your computer has an eject button on the PC Card socket, press the button to release the card. Then, pull the card from the socket;

Or,

If your computer does not have an eject button on the PC Card socket, carefully pull the card straight out from the socket.

Windows 3.1 and Novell, or Windows for Workgroups

1. Log off the network.
2. If your computer has an eject button on the PCMCIA socket, press the button to release the card. Then, pull the card from the socket;

Or,

If your computer does not have an eject button on the PCMCIA socket, carefully pull the card straight out from the socket.

3. The computer will beep when it recognizes that the card is removed.

Technical Support

If you have any difficulties, please refer to the installation guide. For further help, contact Simple Technology Technical Support at the following :

- Tel : 714-476-1180
 - 1-800-367-7330 (US and Canada only)
 - Fax : 714-476-1209
 - EMail : support@simpletech.com
 - Web : <http://www.simpletech.com>
-

Limited Product Warranty

Simple Technology, Inc. ("STI"), warrants that this product will be free from defects in materials and workmanship during the warranty period, and will perform according to product documentation. This warranty is expressly limited to product repair or replacement, at the sole discretion of STI.

Except for the express warranty expressed above, STI grants no other warranty. All implied warranties of merchantability and fitness for a particular purpose are expressly disclaimed and are not applicable to the product. This warranty is contingent upon proper use of the product in the application for which it is intended and does not cover any product that was modified or subjected to unusual physical or electrical stress.

STI's maximum liability for breach of, or resulting from, this warranty will be limited to an amount not exceeding the original product purchase price. In no event will STI be liable to any party for any special, consequential, or incidental damages, or for damages for personal injury or property damage.

The defective product must be returned to original place of purchase with valid proof of purchase. State and local laws may apply.

Ethernet PC Card Product Warranty Period: 5 Years

Copyright

© Copyright 1996 Simple Technology Inc., all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without expressed written consent of STI.

Disclaimer

Specifications subject to change without notice. Simple Technology Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, STI reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of STI to notify any person of such revision.

Trademarks

Simple Technology is a registered trademark of Simple Technology, Inc. Products and brand names are trademarks and/or registered trademarks of their respective companies.

Document Part Number 61000-00009-005

1-800-367-7330

3001 Daimler Street, Santa Ana, California 92705

Tel: (714) 476-1180 Fax: (714) 476-1209

<http://www.simpletech.com>

